FLUKE
70 Series
Multimeters

Service Manual

FLUKE®

27

FLUKE 70 Series Multimeters

Service Manual

P/N 731034
January 1984
©1984 John Fluke Mfg. Co., Inc., all rights reserved. Litho in U.S.A.

FLUKE®

FLUKE 70 SERIES

LIMITED WARRANTY

John Fluke Mfg. Co., Inc., (Fluke) warrants each instrument it manufactures to be free from defects in material and workmanship under normal use and service for the period of 3 years from date of purchase. This warranty extends only to the original purchaser and shall not apply to batteries, fuses, or any instrument which has been subjected to misuse, neglect, accident or abnormal conditions of operation.

Fluke's obligation under this warranty is limited to repairing or replacing, at Fluke's option, an instrument returned to an authorized Service Center within 3 years of the date of purchase, provided Fluke determines that the product fails to conform to this warranty. If the failure has been caused by misuse, alteration or abnormal condition of operation, repairs will be billed at a nominal cost.

ANY IMPLIED WARRANTIES OF MERCHANTABILITY SHALL BE LIMITED TO A PERIOD OF TWELVE MONTHS FROM THE DATE OF PURCHASE. THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER IN CONTRACT, TORT OR OTHERWISE.

NOTE (USA only): Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

If a failure occurs, forward the instrument, postage prepaid, to the closest Service Center with a description of the difficulty. Service Center locations are listed in the Operator's Manual. Repairs will be made at the Service Center and the instrument returned, transportation prepaid. The instrument should be shipped in the original packing carton or in a suitable, rigid container. Fluke shall assume NO risk for damage in transit.

John Fluke Mfg. Co., Inc., P.O. Box C9090, Everett WA 98206

Table of Contents

SECTION		TITLE	PAGE
1		**INTRODUCTION AND SPECIFICATIONS**	**1-1**
	1-1.	INTRODUCTION	1-1
	1-2.	SPECIFICATIONS	1-1
2		**OPERATING INSTRUCTIONS**	**2-1**
	2-1.	INTRODUCTION	2-1
3		**THEORY OF OPERATION**	**3-1**
	3-1.	INTRODUCTION	3-1
	3-2.	OVERVIEW	3-1
	3-3.	DETAILED DESCRIPTION	3-1
	3-4.	Input Signal Conditioning	3-1
	3-5.	Ohms Input Protection	3-1
	3-6.	Additional Circuitry	3-1
4		**MAINTENANCE**	**4-1**
	4-1.	INTRODUCTION	4-1
	4-2.	PWB ACCESS AND GENERAL MAINTENANCE	4-1
	4-3.	DISPLAY ACCESS	4-2
	4-4.	CLEANING	4-2
	4-5.	PERFORMANCE TESTS	4-3
	4-6.	Initial Procedure	4-3
	4-7.	Display Test	4-3
	4-8.	AC Voltage Test	4-3
	4-9.	DC Voltage Test	4-3
	4-10.	Resistance Test	4-3
	4-11.	Diode Test	4-4
	4-12.	DC mA Test (75 & 77 Only)	4-4
	4-13.	DC Amps Test	4-4
	4-14.	CALIBRATION	4-5
	4-15.	TROUBLESHOOTING	4-5
	4-16.	Overall System Check	4-5
	4-17.	VDC Signal Tracing	4-5

(continued on page ii)

TABLE OF CONTENTS, *continued*

SECTION	TITLE	PAGE
5	**LIST OF REPLACEABLE PARTS**	**5-1**
	5-1. INTRODUCTION	5-1
	5-2. HOW TO OBTAIN PARTS	5-1
6	**LIST OF ABBREVIATIONS**	**6-1**
	6-1. INTRODUCTION	6-1
7	**SCHEMATIC DIAGRAMS**	**7-1**

List of Tables

TABLE	TITLE	PAGE
3-1.	S1 Function Codes	3-1
4-1.	Recommended Test Equipment	4-1
4-2.	AC Voltage Test	4-4
4-3.	DC Voltage Test	4-4
4-4.	Resistance Test	4-4
4-5.	DC mA Test	4-5
4-6.	DC Amps Test	4-5
4-7.	Fault Guide	4-6
5-1.	70 Series Final Assembly	5-2
5-2.	70 Series PWB Assembly	5-4
6-1.	Abbreviations	6-1

List of Illustrations

FIGURE	TITLE	PAGE
3-1.	Overview	3-1
3-2.	Ohms Function	3-1
4-1.	Display Assembly	4-3
4-2.	Display Test	4-3
5-1.	70 Series Final Assembly	5-3
5-2.	70 Series PWB Assembly	5-5
7-1.	A1 Main PWB Assembly	7-2

static awareness

A Message From

John Fluke Mfg. Co., Inc.



Some semiconductors and custom IC's can be damaged by electrostatic discharge during handling. This notice explains how you can minimize the chances of destroying such devices by:

1. Knowing that there is a problem.
2. Learning the guidelines for handling them.
3. Using the procedures, and packaging and bench techniques that are recommended.

The Static Sensitive (S.S.) devices are identified in the Fluke technical manual parts list with the symbol "⊗"

The following practices should be followed to minimize damage to S.S. devices.



1. MINIMIZE HANDLING



3. DISCHARGE PERSONAL STATIC BEFORE HANDLING DEVICES



2. KEEP PARTS IN ORIGINAL CONTAINERS UNTIL READY FOR USE.



4. HANDLE S.S. DEVICES BY THE BODY



5. USE ANTI-STATIC CONTAINERS FOR HANDLING AND TRANSPORT



6. DO NOT SLIDE S.S. DEVICES OVER ANY SURFACE



7. AVOID PLASTIC, VINYL AND STYROFOAM® IN WORK AREA



8. WHEN REMOVING PLUG-IN ASSEMBLIES, HANDLE ONLY BY NON-CONDUCTIVE EDGES AND NEVER TOUCH OPEN EDGE CONNECTOR EXCEPT AT STATIC-FREE WORK STATION. PLACING SHORTING STRIPS ON EDGE CONNECTOR USUALLY PROVIDES COMPLETE PROTECTION TO INSTALLED SS DEVICES.



9. HANDLE S.S. DEVICES ONLY AT A STATIC-FREE WORK STATION
10. ONLY ANTI-STATIC TYPE SOLDER-SUCKERS SHOULD BE USED.
11. ONLY GROUNDED TIP SOLDERING IRONS SHOULD BE USED.

Anti-static bags, for storing S.S. devices or pcbs with these devices on them, can be ordered from the John Fluke Mfg. Co., Inc.. See section 5 in any Fluke technical manual for ordering instructions. Use the following part numbers when ordering these special bags.

John Fluke Part No.	Description
453522	6" X 8" Bag
453530	8" X 12" Bag
453548	16" X 24" Bag
454025	12" X 15" Bag
Pink Poly Sheet	Wrist Strap
30"x60"x60 Mil	P/N TL6-60
P/N RC-AS-1200	$7.00
$20.00	

PORTIONS REPRINTED
WITH PERMISSION FROM TEKTRONIX, INC.
AND GENERAL DYNAMICS, POMONA DIV.

® Dow Chemical

J0089B-07U7810/SE EN Litho in U.S.A.

Section 1
Introduction and Specifications

1-1. INTRODUCTION

This manual presents service information for the Fluke 73, 75, and 77 Multimeters. Included are a theory of operation, general maintenance procedures, performance tests, calibration procedures, troubleshooting information, a list of replaceable parts, and a schematic diagram.

1-2. SPECIFICATIONS

For instrument specifications, refer to the Operator's Manual provided with the instrument at time of purchase.

Section 2
Operating Instructions

2-1. INTRODUCTION

For operating instructions, refer to the Operator's Manual provided with the instrument at time of purchase.

Section 3
Theory of Operation

3-1. INTRODUCTION
This section contains a brief overview of the 70 Series Multimeters, followed by a more detailed explanation of operation.

3-2. OVERVIEW
The heart of the instrument is made up of a two-chip CMOS system: U1, a primarily analog IC, and U2, a calculator-style microcomputer. (See Figure 3-1.)

The analog chip, U1, contains the A/D converter and additional circuitry for autorange switching and signal conditioning. With most of the analog circuitry on U1, the off-chip signal conditioning is at the simplest possible level. Peripherals to U1 include function switching, voltage reference and the crystal.

The microcomputer, U2, controls the A/D converter function and range switching, reads and formats the A/D samples, and drives the liquid crystal display (LCD).

3-3. DETAILED DESCRIPTION
The following paragraphs describe the 70 Series Multimeters in more detail. While reading this description, refer to the schematic in Section 7. (The schematic covers all three models.)

3-4. Input Signal Conditioning
Since the A/D conversion process is essentially a dual slope method, two input voltages are required to complete a measurement cycle. One is the unknown input and the other is the reference voltage.

Conditioned input signals are routed to the A/D in U1, where they are integrated. The reference voltage, developed by reference supply VR1, R15, R16, and R8, is routed to the A/D in U1, where it is used for the de-integrate portions of the measurement cycle.

Input voltage signal conditioning is accomplished with input divider Z1 and dc blocking capacitor C1, with pin 1 of Z1 as the input, pin 3 as the 3.2V tap, pin 4 as the 32V tap, pin 5 as the 320V tap, and pin 6 as the 1000V tap. Overvoltage protection is supplied by E1, E2, R1, and R2. E1 and E2 are spark gaps which fire between 1200 and 1800V, and R1 is a fusible wirewound resistor that will open with excessive inputs.

Current input conditioning is achieved by R6, R7, R5, and R13. R6 and R7 develop the input voltage from the applied current, and R5 and R13 act as an input divider for the 300 mA range. F1 and F2 are for overcurrent protection in the mA ranges.

In the ohms function (Figure 3-2), the unknown resistance at J1 is compared to the reference resistors in Z1. This is accomplished by driving current from the ohms voltage source through the reference resistors and the unknown resistance Rx. The developed voltage drops, V1 and V2, are used for ratiometric ohms conversion within the analog chip U1.

3-5. Ohms Input Protection
(Refer to schematic in Section 7). Input protection for the ohms ranges consists of Q1, Q2, Q3, R2, R3, R4, and RT1. Q1 and Q2 serve as back-to-back zener diodes which limit the input to between 7 and 9V. RT1 is a thermistor which normally has about 1 kΩ of resistance but increases to very high impedance as it heats up. Also, R2, R3, and R4 limit current, and Q3 clamps pin 29 of U1 to approximately 2.5V.

3-6. Additional Circuitry
(Refer to schematic in Section 7.) The ratio of R17 and R18 determine ac voltage and current accuracy, and C11 is the averaging capacitor for the ac converter portion of U1.



Figure 3-1. Overview



Figure 3-2. Ohms Function

R10, C5 and C6 are part of the active filter located in [illegible]. Conditioned input signals are passed through the active filter in route to the A/D section of U1.

The clock frequency for the digital portion of the circuit is a function of 32.768 kHz crystal Y1. Y1, C12, and amplifiers in U1 make up the oscillator circuit.

C7 stores offsets of the buffer, integrator, and comparator amplifiers of the A/D. The gain of the buffer is determined by the resistors of Z1 between pins 8, 9, and 10. C8 is the integrator capacitor.

Rotary switch S1 FRONT selects and routes the input signals. Function codes for switch S1 REAR are shown in Table 3-1. Range switch S2 signals the microcomputer U2 for the Touch Hold function (77 only) and the Range Hold function (75 and 77 only).

CR1 acts as protection for U1 if the battery is installed backwards. C2 is part of the power-on reset for microcomputer U2.

Table 3-1. S1 Function Codes

FUNCTION	B0	B1	B2
ACV	1	1	1
DCV	0	1	1
300mV	0	0	0
Ohms	0	0	1
⊣◆ ıı))	1	0	0
ACA	1	1	0
DCA	0	1	0

1 = VDD
0 = ▽ (Common)

Section 4
Maintenance

WARNING

THESE SERVICE INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID ELECTRIC SHOCK, DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN THE OPERATOR'S MANUAL UNLESS YOU ARE QUALIFIED TO DO SO.

4-1. INTRODUCTION

This section contains maintenance information for the Fluke 73, 75 and 77, including performance tests, calibration, general maintenance procedures, and troubleshooting. For operator maintenance and instrument specifications, refer to the Operator's Manual.

The performance tests are recommended as a preventive maintenance tool to verify proper instrument operation. A one year calibration cycle is recommended to maintain the specifications given in the Operator's Manual. Test equipment required for the performance tests and calibration is listed in Table 4-1. If the recommended equipment is not available, instruments with equivalent specifications may be used.

4-2. PWB ACCESS AND GENERAL MAINTENANCE

WARNING

TO AVOID ELECTRICAL SHOCK, REMOVE TEST LEADS BEFORE OPENING CASE, AND CLOSE CASE BEFORE OPERATING METER. TO PREVENT FIRE, INSTALL FUSES WITH RATING SHOWN ON BACK OF METER.

CAUTION

To avoid contaminating the pwb with oil from the fingers, handle it by the edges or wear gloves. PWB contamination may not cause immediate instrument failure in controlled environments. Failures typically show up when contaminated units are operated in humid areas.

Use the following procedure for removing the pwb (printed wire board) from its case:

1. Set the function switch to OFF and disconnect test leads if installed.
2. Remove the four Phillips screws from the bottom cover.
3. Turn the meter face up, grasp the top cover, and pull the top cover from the meter.
4. For 75 and 77 meters, lift fuse F2 before removing the Phillips screw that holds the pwb to the back cover. The Model 73 is not fused. BE CAREFUL NOT TO LOSE THE SPRING LOCATED DIRECTLY UNDER

THE SCREW ON THE BACK SIDE OF THE PWB.

5. The pwb may now be removed from the bottom cover.

4-3. DISPLAY ACCESS

CAUTION

Do not handle the conductive edges of the LCD interconnects. If contaminated, clean with isopropyl alcohol.

Refer to Figure 4-1.

1. Remove the four Phillips screws from the back side of the pwb.
2. Remove the LCD mounting bracket.
3. Insert a small screwdriver under the edges of the display holding bracket, and gently pry the bracket loose from the snaps.
4. Turn the bracket upside down to remove the LCD.
5. Before installing a new LCD, make sure that all connector contact points are clean.

4-4. CLEANING

CAUTION

To avoid damaging the meter, do not use aromatic hydrocarbons or chlorinated solvents for cleaning. These solutions will react with the plastics used in the instruments.

Do not allow the liquid crystal display to get wet. Remove the display assembly before washing the PWB and do not install until the PWB is completely dry.

Do not use detergent of any kind for cleaning the PWB.

Do not remove lubricants from the switch when cleaning the PWB.

Clean the instrument case with a mild detergent and water.

The pwb may be washed with isopropyl alcohol or deionized water and a soft brush. Remove the display assembly and fuses before washing, and avoid washing the switch if possible. Dry with clean dry air at low pressure and then bake at 50°C for 24 hours.

Table 4-1. Recommended Test Equipment

INSTRUMENT TYPE	REQUIRED CHARACTERISTICS	RECOMMENDED MODEL
PREFERRED		
DMM Calibrator	John Fluke 5100B Family	John Fluke Models 5100B, 5101B or 5102B
ALTERNATE		
AC Calibrator	Voltage Range: 0-750V ac ± 0.3% Frequency Range: 40-1000 Hz ± 3%	John Fluke Models 5200A and 5215A
DC Voltage Calibrator	Voltage Range: 0-1000V dc Accuracy: ± .03%	John Fluke Model 343A
DC Current Calibrator	Current Range: 2 mA - 2A Accuracy: ± .15%	John Fluke Model 382A
Decade Resistor	Resistance Values: 100Ω, 1 kΩ 10 kΩ, 100 kΩ, 1 MΩ, 10 MΩ, Accuracy: ± .1% Power Rating: 1/8 W	ESI Model DB 62



Figure 4-1. Display Assembly

4-5. PERFORMANCE TESTS

Performance tests are recommended for incoming inspection, periodic maintenance, and for verifying the specifications in the Operator's Manual. If the instrument fails any part of the test, calibration and/or repair is indicated.

In the performance tests, the Fluke 70 Series Multimeter is referred to as the unit under test (UUT).

4-6. Initial Procedure

1. Allow the UUT to stabilize to room temperature 23°C ± 5°C (73°F ± 9°F).

2. Check the fuses and battery and replace if necessary.

WARNING

TO PREVENT FIRE, INSTALL FUSES WITH RATING SHOWN ON BACK OF METER.

4-7. Display Test

To test the display, turn the UUT on and check whether all display segments come on as indicated in Figure 4-2.



Figure 4-2. Display Test

4-8. AC Voltage Test

WARNING

CONNECT THE GROUND/COMMON/LOW SIDE OF THE AC CALIBRATOR TO COMMON ON THE UUT.

1. Put the UUT function switch to VAC and connect the AC Calibrator to the V-Ohm and Common input terminals.

2. Set the AC Calibrator for the output given in Table 4-2 and verify that the UUT display reading is within the limits shown.

NOTE

When the input is open in the VAC function, it is normal for the 70 Series Multimeters to read some counts on the display. This is due to ac pickup in the ac amplifier when the ac amplifier is unterminated.

4-9. DC Voltage Test

WARNING

CONNECT THE GROUND/COMMON/LOW SIDE OF THE DC CALIBRATOR TO COMMON ON THE UUT.

1. Put the UUT function switch to VDC and connect the DC Voltage Calibrator output to the V-Ohm and Common input terminals of the UUT.

2. Referring Table 4-3, set the DC Voltage Calibrator for the output indicated in steps 1 through 4 only. Verify that the UUT display reading is within the limits shown.

3. Set the DC Voltage Calibrator for an output of +300 mV, and switch the UUT to the 300 mV function. Verify that the UUT display reading is within the limits shown in Table 4-3 (step 5).

4-10. Resistance Test

1. Select the ohms function on the UUT.

2. Connect the Fluke 5100B or Decade Resistor to the V-Ohm and Common input terminals of the UUT.

3. Referring to Table 4-4, set the Decade Resistor or Fluke 5100B to the resistance value indicated in steps 1 through 6. Verify that the display reading is within the limits shown.

4-11. Diode Test

To test the 75 and 77 meters, perform the following steps:

1. Put the UUT in the Diode Test function.

NOTE

On Fluke 5100 series calibrators, activate the 50Ω divider override.

2. Apply an input from the DC Voltage Calibrator of +.090V dc to the V-Ohm and Common input terminals of the UUT and verify that the beeper is on.

3. Increase the DC Voltage Calibrator output to +.110V dc and verify that the beeper is off.

To test the 73 meter, apply an input from the DC Voltage Calibrator of +2V dc to the V-Ohm and Common input terminals of the UUT. Verify that the display reading is between +1.960 and +2.040.

4-12. DC mA Test (75 & 77 Only)

1. Set the output of the DC Current Calibrator to zero and connect it to the 300 mA and Common input terminals of the UUT.

2. Set the DC Current Calibrator to the output shown in Table 4-5, and verify that the UUT display reading is within the limits shown.

4-13. DC Amps Test

1. Set the DC Current Calibrator for zero output and connect it to the 10A & Common input terminals of the UUT.

2. Apply currents as indicated in Table 4-6 and verify the display reading is within the limits shown.

Table 4-2. AC Voltage Test

STEP	INPUT		DISPLAY READING		
	VOLTAGE	FREQ.	73	75	77
1	2.7V	100 Hz	2.617 to 2.783	2.644 to 2.756	2.644 to 2.756
2	2.7V	500 Hz	2.617 to 2.783	2.644 to 2.756	2.644 to 2.756
3	750V	100 Hz	725 to 775	733 to 767	733 to 767
4	750V	1000 Hz	725 to 775	733 to 767	733 to 767

Table 4-3. DC Voltage Test

STEP	DC INPUT VOLTAGE	DISPLAY READING		
		73	75	77
1	+2.7V	2.680 to 2.720	2.685 to 2.715	2.691 to 2.709
2	+27V	26.80 to 27.20	26.85 to 27.15	26.91 to 27.09
3	+270V	268.0 to 272.0	268.5 to 271.5	269.1 to 270.9
4	+1000V	991 to 1009	993 to 1007	995 to 1005
5*	+300 mV	297.8 to 302.2	298.4 to 301.6	299.0 to 301.0
*300mV function only				

Table 4-4. Resistance Test

STEP	INPUT RESISTANCE	DISPLAY READING		
		73	75	77
1	100Ω	98.8 to 101.2	99.1 to 100.9	99.3 to 100.7
2	1000Ω	989 to 1011	992 to 1008	994 to 1006
3	10 kΩ	9.89 to 10.11	9.92 to 10.08	9.94 to 10.06
4	100 kΩ	98.9 to 101.1	99.2 to 100.8	99.4 to 100.6
5	1 MΩ	.989 to 1.011	.992 to 1.008	.994 to 1.006
6	10 MΩ	9.69 to 10.31	9.74 to 10.26	9.79 to 10.21

Table 4-5. DC mA Test

STEP	INPUT CURRENT	DISPLAY READING
		75 & 77
1	+27 mA	26.58 to 27.43
2	+200 mA	195.8 to 204.2

Table 4-6. DC Amps Test

STEP	INPUT CURRENT (5100B)	DISPLAY READING	
		73	75 & 77
1	+1.99999A dc	1.94 to 2.06	1.95 to 2.05

4-14. CALIBRATION

1. Set the DC Voltage Calibrator to zero and set the UUT to the VDC function.

2. Connect the DC Voltage Calibrator to the V-Ohm and Common input terminals of the UUT.

3. Set the DC Voltage Calibrator for an output of +3V dc and adjust R8 for a display reading of +3.000V dc ± .001V.

4-15. TROUBLESHOOTING

A fault guide for the 70 Series Multimeters is given in Table 4-7. This guide can be helpful in isolating troubles to a component area. Also, procedures are given below to help isolate the troubles further. In these procedures, the 70 Series Multimeter is referred to as the unit under test (UUT).

When troubleshooting the 70 Series Multimeters, use the precautions listed on the static awareness sheet to prevent damage from static discharge.

4-16. Overall System Check

Make the following checks in the order listed. All measurements are made with respect to common.

1. Put the UUT function switch in the VDC position.

2. Using a DVM, check +VDD (TP-1) or the positive battery post for 3.1V dc ± .1V.

   Probable failure: BT1, CR1, U1, loose battery connector

3. Connect an oscilloscope or counter to pin 54 of U1 or to the junction of C12 and Y1 crystal. Check for a 32.768 kHz sine wave approximately 600 mV p-p in amplitude. Note that U2 and the display will not work if the clock circuit is not working.

   Probable failure: U1, Y1, or C12

4. Check for a reference voltage of 1.00V dc (adjustable by R8) at pin 14 of U1 or the junction of R15 and R16.

   Probable failure: R8, R14, R15, R16, VR1, or CR2

5. Check that VM (V middle) is 1.6V dc ± .1V at pin 28 of U2 or at the junction of R11 and R12.

   Probable failure: R11, R12 or C10

4-17. VDC Signal Tracing

Make the following checks in the order listed. All measurements are made with respect to common.

1. Put the UUT in the VDC function and apply 2V dc to the input.

2. Using a DVM, measure the input at J1 for 2V dc.

3. Measure pin 1 of Z1 input divider for 2V dc.

   Probable failure: R1, S1, E1

WARNING

R1 IS A FUSIBLE RESISTOR. TO ENSURE SAFETY, USE EXACT REPLACEMENT ONLY.

NOTE

Measurements in steps 4, 5, and 6 may be affected by loading.

4. Measure Z1 pin 3 for 200 mV dc.

   Probable failure: Z1, U1

5. Measure for 200 mV dc at the active filter input (AFI, pin 26 of U1 or R9).

   Probable failure: U1

6. Measure for 200 mV at the active filter output (AFO, pin 27 of U1 or R9).

   Probable failure: R9, C5 or C6

Table 4-7. Fault Guide

SYMPTOM	ACTION	POSSIBLE COMPONENT
Blank display	Follow overall system check (paragraph 4-16)	BT1, U1, U2, Y1, CR1, C12
Display reads zero in volts function	Trace DC signal (paragraph 4-17)	E1, R1, Z1, R9, U1, S1
Display hangs up in power-up self test (see Figure 4-2)	Follow overall system check (paragraph 4-16)	R14, R8, R15, R16, VR1, C7, C8, Z1, CR2, U1
Display reads OL or zero in 300mA		R13, U1
Display reads zero in 300mA or 10A current ranges		F1 or F2, R6, R5, R13
AC volts is not accurate		R17 & R18
Display reads OL in 300mV range		Q3 shorted, U1
AC volts noisy at 50 to 60 Hz		R9, R10, C5, C6
Display has wrong annunciator called	Check Table 3-1 for correct codes	S1 REAR, U1
Volts inaccurate		Check calibration
Ohms inaccurate		Z1, U1
Intermittent display	Clean connectors and connector strips of the LCD and pwb	Display assembly
Display reads constant offset in volts		C5, C6, or C7 shorted
Ohms reads low or won't read OL		Q1 or Q2 shorted or leaky, E1, E2
Ohms reads randomly or flashes between on-scale and OL		R1, RT1

Section 5
List of Replaceable Parts

5-1. INTRODUCTION

This section contains an illustrated parts breakdown of the 70 Series Multimeters. Both electrical and mechanical parts are listed alphanumerically by reference designator or item number. Each listed component is shown in an accompanying illustration unless otherwise noted.

Parts lists include the following information:

1. Reference designation or item number
2. Description of each part
3. Fluke part number
4. Total quantity per instrument model

5-2. HOW TO OBTAIN PARTS

Components may be ordered from John Fluke Mfg. Co., Inc. factory or authorized representative listed in the Operator's Manual by using the FLUKE PART NUMBER. In the event the part your order has been replaced by a new or improved part, the replacement will be accompanied by an explanatory note and installation instructions, if necessary.

To ensure prompt and efficient handling of your order, include the following information:

1. Quantity
2. Fluke part number
3. Description of part
4. Printed wire board (pwb) part number and revision letter as printed in ink on the board.
5. The reference designation or item number of the part.
6. Instrument model and serial number.

Table 5-1. 70 Series Final Assembly

REF DES ITEM NO.	DESCRIPTION	FLUKE PART NO.	TOTAL QTY WHERE USED 73	75	77
		835363			
Not	Case Assembly, Top	~~652552~~	0	0	1
Illustrated	Case Assembly, Top	656752	0	1	0
"	Case Assembly, Top	656116	1	0	0
"	Case Assembly, Bottom	654095	0	1	1
"	Case Assembly, Bottom	661009	1	0	0
"	Decal, Bottom (Ital,Jpn)	698506	1	1	1
"	Decal, Bottom (Ger,Fr,Span)	698514	1	1	1
106	Transducer	642991	0	1	1
107	Contact, Annunciator	642983	0	1	1
111	Spring, Coil	697227	1	1	1
116	Screw,Thread forming	519116	1	1	1
206	Window, LCD	~~661314~~ 791376	0	0	1
206	Window, LCD	642108	0	1	0
206	Window, LCD	642082	1	0	0
207	Bracket, LCD	646653	1	1	1
208	Mask, Bracket	642090	1	1	1
209	Connector, LCD to PWB	649632	2	2	2
216	Screw, Thread forming	448456	4	4	4
241	Screw, Thread forming	447953	4	4	4
246	Foot, Non skid	640565	4	4	4
301	Decal	680678	0	0	1
301	Decal	642926	0	1	0
301	Decal	680561	1	0	0
Not	Manual, Operator's	642025	0	1	1
Illustrated	Manual, Operator's	704601	1	0	0
"	Test leads, one set	~~642033~~ TL70A	1	1	1
"	* C70 Holster	708263	0	0	1

* C70 Holster may be ordered as an accessory for Fluke 73 and 75. Order from distributor or local representative.



Figure 5-1. 70 Series Final Assembly

Table 5-2. 70 Series PWB Assembly

REF DES ITEM NO.	DESCRIPTION	FLUKE PART NO.	TOTAL QTY WHERE USED 73	75	77
BT1	Battery, 9 Volt	696534	1	1	1
C1	Cap, .022 uF, 1000V	721019	1	1	1
C2,C10	Cap, .47 uF, 35V, 20%	655035	2	2	2
C4	Cap, 2.2 uF, 50V, 20%	650069	1	1	1
C5,C6	Cap, .027 uF, 50V, 10%	720979	2	2	2
C7	Cap, .47 uF	697409	1	1	1
C8	Cap, .033 uF, 50V, 5%	721050	1	1	1
C9	Cap, 6.8 uF, 10V, 20%	655043	1	1	1
C11	Cap, 2.2 uF, 16V, 20%	706804	1	1	1
C12	Cap, 47 pF, 50V, 20%	706705	1	1	1
C13	Cap, .22 uF, 50V, 20%	649939	1	1	1
CR1,CR2	Diode, 1N4448	659516	2	2	2
E1,E2	Spark Gap	729202 LITTLEFUSE	2	2	2
F1	Fuse, 630 mA, 250V IEC 127/II, 5x20 mm	658658 216.630	0	1	1
F2	Fuse, Fiber, 3A, 600V	475004 BBS-3	0	1	1
Q1,Q2,Q3	Xstr, SM Signal	685404	3	3	3
R1	* Res, Fixed, 1k, WW Fusible 2W	650085	1	1	1
R2,R3	Res, Fixed Cermet 1M, 1W, 5%	655175	2	2	2
R4	Res, 100k, 1/4W, 5%	658963	1	1	1
R5	Res, 390k, 1/4W, 5%	706754	1	0	0
R5	Res, 402k, 1/4W, .25%	706739	0	1	1
R6	Res, Fixed, 4.99 ohms, 1% +/- 50 ppm	655019	0	1	1
R7	Res, Fixed, .005 ohms, 1% +/- 50 ppm	631960	1	1	1
R8	Res, Var, 100k, 20%	649897	1	1	1
R9,R19	Res, 1M, 1/4W, 5%, CF	649970	2	2	2
R10	Res, 1.5M, 1/4W, 5%, CF	649962	1	1	1
R11	Res, 332k, 1/8W, 1%	655217	1	1	1
R12	Res, 301k, 1/8W, 1%	655274	1	1	1
R13	Res, 44.8k, 1/8W, .25%	706747	0	1	1
R14	Res, 62k, 1/4W, 5%, CF	713941	1	1	1
R15	Res, 56.2k, 1/8W, 1%	706242	1	1	1
R16	Res, 205k, 1/8W, 1%	706234	1	1	1
R17	Res, 20.5k, 1/8W, 5%	682716	1	1	1
R18	Res, 9.20k, 1/8W, 5%	715219	1	1	1

* WARNING--FUSIBLE RESISTOR. TO ENSURE SAFETY, USE EXACT REPLACEMENT ONLY.

Table 5-2. 70 Series PWB Assembly (cont)

REF DES ITEM NO.	DESCRIPTION	FLUKE PART NO.	TOTAL QTY WHERE USED 73	75	77
RT1	Res, Thermistor, PTC 1k	446849	1	1	1
S1	Switch, Rotary	642918	1	1	1
U1	A/P 75	683052→791269	1	1	1
U2	Microcomputer, CMOS 4-Bit	659656→791277	1	1	1
U3	LCD	640581	1	1	1
VR1	Voltage Ref, 1.23V	634451	1	1	1
W1	Res, zero ohm	682575	0	1	0
W2	Res, zero ohm	682575	0	0	1
W3▷	Res, zero ohm	682575	1	0	0
W4▷	Res, zero ohm	682575	1	0	0
Y1	Crystal, 32.768 kHz	643031	1	1	1
Z1	Res, network	683797	1	1	1

▷ NOTE: In Fluke 73, W3 replaces R6, and W4 replaces R13.



75-1601

Figure 5-2. 70 Series PWB Assembly

Section 6
List of Abbreviations

6-1. INTRODUCTION

This section contains a list of definitions for abbreviations used in the schematic drawings for the 70 Series Multimeters.

Table 6-1. Abbreviations

ABBREVIATION	DEFINITION
ACA	AC Converter Feedback
ACHI	AC Converter High
ACL	All Clear, Reset
ACLO	AC Converter Low
AFI	Active Filter Input
AFO	Active Filter Output
AMO	Amps Input
AM1	Amps Divide by 10
AZ	Auto Zero Point
BPR	Beeper Driver
BT	Battery
CLK	Clock Output
COM	Common
DCS	DC Sense
EC	Reference Voltage
FAO	Active Filter Amp Output
FA(-)	Active Filter Amp Feedback
INT	Integrator Output
K0	Buffer Divide By 1 Output
K1	Buffer Divide by 3 Output
LS	Loud Speaker
LO	Low
OHS	Ohms Sense
RNG	Range
RRS	Reference Resistor Sense
RT	Thermistor
VSS	Negative Supply Voltage
VDD	Positive Supply Voltage
VM	Volts Middle
WW	Wirewound
XTL	Crystal Oscillator Inputs
Z	Impedance

Section 7
Schematic Diagram

7-1. INTRODUCTION

This section presents a schematic diagram for the Fluke 73, 75, and 77 Multimeters. Differences between the models are noted.



FLUKE 75/77 T&B

Figure 7-1. A1 Main PWB Assembly


WARNING: R1 IS A FUSIBLE RESISTOR. TO ENSURE SAFETY, USE EXACT REPLACEMENT ONLY.
NOTES: UNLESS OTHERWISE SPECIFIED:
1. ALL CAPACITANCE IS IN MICROFARADS.
2. ALL RESISTANCE IS IN OHMS, 1/4W 5% 1% AND 0.5% RESISTORS ARE 1/8W.
5 MODELS 75 & 77 ONLY
6 FOR MODEL 73, R13 IS REPLACED BY W4
7 C13 REV K PWB ONLY
SI POSITIONS PROCEDING CLOCKWISE
1 OFF
2 AC VOLTS
3 DC VOLTS
4 OHMS, VDC
5 DIODE TEST/CONTINUITY
7 AC CURRENT
8 DC CURRENT
SI IS SHOWN IN THE OFF POSITION
BARGRAPH SEGMENTS
LCD
SM5 U2
#791277
AP 75 U1
#791269
75-1601

Figure 7-1. A1 Main PWB Assembly (cont)